



Tekplas 2 or 3 Rail Ranch Fencing Assembly Instructions

Table of Contents

Kit List	3
2 or 3 Ranch Rail Fencing	3
Tools Required	3
Recommended	3
Tekplas 2 or 3 Ranch Rail Link Fencing.....	4
Cementing Post.....	4
Ground Spike	5
Ranch Rail 2	5
Ranch Rail 3	6

Kit List

2 or 3 Ranch Rail Fencing

- 1 x Post Section (height depends on variation chosen)
- 1 x End Cap for Post
- 2 x Spacer 550mm or 750mm long
- 2 x Slot Cover 600mm Long
- 1 x Steel Ground Spike 700mm
- 2 or 3 x Ranch Panels 1150mm Long

Tools Required

- Hammer / Mallet
- Spirit Level

Recommended

- Plastic PVC Glue (Not Supplied) – Superglue, Mitrebond, Solvent Cement
- Postcrete or Cement

Tekplas 2 or 3 Ranch Rail Link Fencing

1. Knock the steel spike into the ground (suitable for soft ground, if the ground is hard then cement in using instructions below). If the ground is hard then dig a hole for the steel and ensure the steel is level using a spirit level.

Cementing Post

1. Dig the hole for your first post.
2. Fix the post into the ground using Postcrete or similar product. These are ready-made cement bags that just need to be filled around the post and then add the correct amount of water.
3. Use a spirit level to make sure the post is square all round and leave the cement to set.
4. Pack the earth on top of the cement around the post.
5. Slide one rail into the first post, attach the second post to the other side of the rail and mark out where the 2nd post needs to be fixed.
6. Remove the spike, post and rail
7. Now dig the hole for your 2nd post and cement in place with your cement mix of choice and follow **step 2**.
8. Now fit the spacer down each post and then the first rail and repeat the process till all rails are in place.
9. Repeat the process for the remaining posts.

Ground Spike

1. Knock the ground spike into the ground using a spirit level to make sure the spike is level all around.
2. Fit the post over the ground spike.
3. Use the rails to help fix the 2nd post into position.
4. Slide one rail into the first post, attach the second post to the other side of the rail and mark out where the 2nd post needs to be fixed.
5. If you are using spikes – slide the spike down the centre of the post and hit the spike lightly to make the ground.
6. Remove the spike, post and rail.
7. Fix the spike into the ground, using a hammer, ensuring that it is level.
8. Now fit the spacer down each post and then the first rail and repeat the process till all rails are in place.
9. Repeat the process for the remaining posts.

NOTE: Post caps are to be glued on and left to fully bond after the pen has been fully assembled.

Ranch Rail 2

The first rail is spaced 290mm from the ground. Once it has been fitted cut a piece of spacer 100mm long then fit the second rail. This leave a 10mm gap to the top of the post

Ranch Rail 3

The first rail is spaced 390mm from the ground. Once it has been fitted cut a piece of spacer 100mm long then fit the second rail. This leave a 10mm gap to the top of the post